


The area with a small notch is the front of the device



Place the device on a flat surface and insert it into the corresponding notch in the base.
Use the screws in the accessory pack to fix it.