



1. Place the display vertically on the ground
2. Pull up the bracing bracket, moving the bracing pole to its limit position (it should not fall when released)
3. Slowly lower the display, shake the display until it does not loosen